


## Meet Your Mobile Hotspot

Before you connect your mobile hotspot, familiarize yourself with its LCD screen, icons, buttons, and connectors.

You can connect up to 15 Wi-Fi devices (such as smartphones, laptops, tablets, digital cameras, printers, gaming consoles, and digital picture frames) to your mobile hotspot



## Control Your Device Using the Power Button

The Power button is used to turn the NETGEAR Mobile Hotspot on or off and to choose which information screen to display on the LCD:

- Turn mobile hotspot on. Press and hold the Power button for 3-4 seconds
- Turn mobile hotspot off. Press and hold the Power button for 3-4 seconds
- Wake up Wi-Fi signal and device screen. Press and release the Power button.
- Cycle through screens. Press and release the Power button.

## Status LED


The status LED indicates data connection status:

- Blue, slow blink. The mobile hotspot is ready.
- Blue, double-blink. The mobile hotspot is transferring data.
- Amber, slow blink. The mobile hotspot is not connected to the network or is in standby mode.

## Connect to the Internet

### To connect to the Internet:

1. Press and release the **Power** button to turn on the mobile hotspot.



2. On your laptop or Wi-Fi device, open your Wi-Fi network connection manager.
3. Connect your device to the hotspot with the Wi-Fi name and password.

**Note:** Your Wi-Fi network name is different from this example.

## Recharge the Battery

Your battery comes partially charged.

### To recharge your battery:

1. Connect the micro USB charging cable to your mobile hotspot.



2. Connect the other end of the cable to the USB port on your computer or to the USB charger.